
TOUCH PANEL CONTROL BOARD 4-WIRE USB

N16B-0558-B710 USB Interface Controller Board Quick Reference


4-Wire Resistive Touch Panels






■ FEATURES

- High quality and reliability touch panel control board with integrated switch for selectable cable tail exit direction for FPC cable 4-wire touch panels.
- USB 1.1 bus powered interface for direct connection to PC or alternative USB interfaces.



■ SWITCH SETTINGS



Connector Pin Assignment listed on individual touch panel drawings.

1

USB 4 -Wire Control Board

■ CONSTRUCTION

Specification Item		N16B-0558-B720 7-Wire USB Control Board		
Mechanical	Size / Weight	75mm x 30mm / 30g		
Electrical	Supply Voltage (max./min.)	Vcc 5.5V/4.1V		
	Operating current (detect)	36 mA at Vcc = 5V and T = 25 degrees		
	Sleep Mode current	6 mA at Vcc = 5V and T = 25 degrees		
Environment	Operating Temperature	-5° C to +60° C		
	Storage Temperature	-30° C to +70° C		
	Humidity	20%RH to 85% RH at +38° C maximum wet bulb temperature		

■ INTERFACE CONNECTION CN2 (JST #: S5B EH)

1.	+5V (Vcc)	3.	D-(Signal)	5.	Frame Ground
2.	D+ (Signal)	4.	Ground		

Complete specification document is available on request for customers with whom we have an approved NDA in place.

Fujitsu Components International Headquarter Offices Japan

Fujitsu Component Limited Gotanda-Chuo Building

3-5, Higashigotanda 2-chome, Shinagawa-ku

Tokyo 141, Japan Tel: (81-3) 5449-7010 Fax: (81-3) 5449-2626 Email: promothq@ft.ed.fujitsu.com

Web: www.fcl.fujitsu.com

North and South America

Fujitsu Components America, Inc. 250 E. Caribbean Drive Sunnyvale, CA 94089 U.S.A. Tel: (1-408) 745-4900 Fax: (1-408) 745-4970 Email: marcom@fcai.fujitsu.com Web: www.fcai.fujitsu.com

Europe

Fujitsu Components Europe B.V.

Diamantlaan 25 2132 WV Hoofddorp Netherlands Tel: (31-23) 5560910 Fax: (31-23) 5560950 Email: info@fceu.fujitsu.com Web: www.fceu.fujitsu.com

Asia Pacific

Fujitsu Components Asia Ltd. 102E Pasir Panjang Road #04-01 Citilink Warehouse Complex

Singapore 118529 Tel: (65) 375-8560 Fax: (65) 273-3021 Email: fcal@fcal.fujitsu.com www.fcal.fujitsu.com

© 2004 Fujitsu Components America, Inc. All company and product names are trademarks or registered trademarks of their respective owners. Rev. 04/28/2004.